

Swim Spa Maintenance Schedule

E-Series • X-Series • R-Series



| SCHEDULE | ACTIONS |
|--------------------------|--|
| EVERY USE | <ul style="list-style-type: none"> • Test your water with a test strip once a week or each time the swim spa is used <ul style="list-style-type: none"> • Test for sanitizer level and record in test log. Adjust as needed. • Test for pH and record in test log. Adjust as needed. |
| WEEKLY | <ul style="list-style-type: none"> • Test for total alkalinity and record in test log. Adjust as needed. • Test for total chlorine and record in test log. Shock as needed. • Check and clean skimmer baskets |
| EVERY MONTH | <ul style="list-style-type: none"> • Test for calcium hardness and record in test log. Adjust as needed. • Test for cyanuric acid if using stabilized chlorine and record in test log • Remove and clean filter cartridges • Clean the cover |
| EVERY FOUR MONTHS | <ul style="list-style-type: none"> • Replace filter cartridges • Replace Nature2 (if present) |
| ANNUALLY | <ul style="list-style-type: none"> • Replace UV lamp (if present) • Drain 50% of water from swim spa and refill with fresh water. Check and adjust calcium hardness level at this time. • Inspect color/condition of hydraulic fluid (if present) |
| AS NEEDED | <ul style="list-style-type: none"> • Add water to maintain the proper level • Use stain and scale preventer • Wipe the stainless steel grab bar(s) with a non-metallic scouring pad • If water is cloudy or shell feels slippery, shock the swim spa by increasing the free chlorine level to 5ppm. Maintain a free chlorine level of 5ppm until the water is clear. If shell is still slippery, brush all surfaces using nylon pool brush. • Clean swim spa shell and pillows • Clean swim spa cabinet |
| ADDITIONALLY | <p>E-Series - Swimming Machine, Treadmill, and Hydraulic Maintenance</p> <ul style="list-style-type: none"> • Replace hydraulic fluid and oil filter in the hydraulic power unit after 500 hours of use and when replacing the underwater hydraulic motor(s) • After 6 years of operation, replace underwater hydraulic motor of the swimming machine AND underwater hydraulic motor and drive belt of optional treadmill (if present). • While replacing underwater hydraulic motor(s), inspect the submersible hydraulic hoses. Replace hoses if necessary. |